

# Which HQ Avante do you have?

Look under your front handlebar assembly...

## STYLE A:

If you have a newer model, you will see a square, phonejack-style connector as shown at right (see the green circle)

Your QBOT Connector Cord will plug directly into that port.



## STYLE B:

If you have an older model, you WILL NOT see a square, phonejack-style connector under your handlebar assembly [green rectangle above in Style A].

Therefore, your QBOT Connector Cord will plug into the port shown at right (see the green rectangle) using our adapter.

